

California AFO Brace Application



1. Place foot inside California AFO Brace with heel back as far into brace as possible.



2. Secure the large, upper strap.



3. Next, secure the very top smaller strap. The tongue should be outside the brace; not tucked in. It can be trimmed with scissors.



4. Pull Arch Suspender Strap upward to lift arch.



5. Wind Arch Suspender Strap around ankle and secure back on itself. The Velcro strap can be trimmed with scissors.



6. Slip foot and finished brace into shoe using horn.